

K55 Series
GUIDE BOOK



K55 Series

Duplicity of minimalism design and luxuriousness, K55

The design purpose of K55 is represented as minimalism which minimizes the exposure of the lumbar support and shows refined design line. At the same time, K55 can present sophisticated image with its unique design and maximum functionality.

INDEX

Function	5
Material & Variation	6
Color Chart	7
Assembly Guide	8
User Guide	10






ADJUSTABLE HEADREST

The headrest is height-adjustable to help the user's head maintain comfortable position.



3D ADJUSTABLE ARMRESTS

Armrest are adjustable in 3D, height, depth and pivot rotation to make the most comfortable use for every user.




SEAT DEPTH SLIDING

Seat depth adjustable to suit user's position.



SYNCHRONIZED MECHANISM

- 4 steps angle adjustment (Left lever)
- 3 steps tilting tension adjustment (Right lever)
- Height adjustment (Right lever)



BASE & CASTER

K55 is using engineering plastic starbase and urethane casters.



K55
TASK CHAIR



K55A

K55B

K55A-BS

K55B-BS

HEADREST - PA + GF30 frame - Fabric upholstered PU foam	•		•	
BACKREST - PA + GF30 frame , PP + GF30 inner shell - Fabric Upholstered PU foam	•	•	•	•
ARMREST - PA+30GF frame - PU foam pad	•	•	•	•
SEAT - PP + GF30 frame - Fabric Upholstered PU foam	•	•	•	•
GAS CYLINDER - Optional stroke : 70mm / 110mm - Class 4	•	•	•	•
BASE - 350 PA Base	•	•	•	•
CASTER - 60mm PU caster	•	•	•	•
DIMENSION	W690 x D740 x H1245	W690 x D740 x H1080	W690 x D740 x H1245	W690 x D740 x H1080

K55

TASK CHAIR



FABRIC

MB series
- HEADREST
- BACKREST
- SEATREST



BLACK
MB-05



GRAY
MB-03



BEIGE
MB-02

FABRIC **


WTT series
- HEADREST
- BACKREST
- SEATREST



MIX BEIGE
WTT-22



DUSTY BLUE
WTT-48




SAMBA RED
WTT-46

** There would be a price increase if WTT-series is used. Please consult with KREDE.

Printed color could be different with the actual fabric color. Please check the actual swatch sample.

Headrest Parts



A
Allen Wrench (small)



B
M6x12 (2)



C
Headrest Cap

Backrest Parts



D
M8x20 (3)




E
M8x13x2 (3)




F
M8x20x2 (3)

Armrest Parts



G
Allen Wrench




H
M6x55 (4)

step 01

Base and Gas Cylinder Assembly





Put gas cylinder onto the base.



Assemble casters onto the base.


step 02

Backrest and Armrest Assembly




Tighten bolt (D→E→F) using a wrench (G).

step 03
Armrest Assembly



Assemble armrests and backrest using bolts (H) as above image.
Tighten bolts using a wrench (G).

step 04
Base and Body Assembly





Complete the assembly of the seat and armrests and then connect with gas cylinder by putting it into the hole of tilt mechanism underneath the seat.

Assembly following as above image is recommended.

When the base is assembled, cautiously stand the chair upright.

step 05
Headrest Assembly **




Assemble the headrest and backrest using bolts(B). Tighten bolts using a wrench (A).

Insert headrest cap while an arrow on the cap heading upward.


Synchronized Tilt Mechanism

T787




- 4 steps angle adjustment (Left lever)
- 3 steps tilting tension adjustment (Right lever)
- Height adjustment (Right lever)

Angle Adjustment




Lock to the preferred backrest angle by simply rotating the lever on your left side counterclockwise. To unlock the angle, rotate the lever clockwise and slightly push the backrest backward. (Anti-shock function)

Height Adjustment



Push up the flat lever on your right side to adjust the height. If you adjust the lever while standing, the seat goes up and the seat goes down while sitting.

Tilting Tension Adjustment



Adjust the tilting tension by simply rotating the lever on your right side. To make strong tension, please rotate the lever clockwise. To make soft tension, please rotate the lever counterclockwise.

Headrest

Height Adjustment



Adjust the height by sliding the headrest up and down.

Armrest

Height Adjustment



Adjust the height while pushing a button underneath the arm pad.


Seat

Depth Adjustment



Adjust the seat depth by pulling the lever underneath your right-side seat. While pulling the lever, you can slide the seat forward to make it deep. To return to the original position, slightly stand up and pull the lever again.

Depth / pivot Rotation



Adjust the position of an armrest in 2 ways without pushing a button.

Warning

01. Do not use the chair for the purpose other than it originally meant to be.
02. Please be advised that the warranted weight capacity of the chair is 113kgs or less.
03. If you put excessive impact on the chair while tilted, it may be damaged.
04. Leaning on unfolded chair from behind could fold the chair and lead to injuries.
05. Do not press the backrest while someone is seated on the chair.
06. Do not push the chair when someone is seated.
07. Please do not use each chair more than two person.
08. Take care to avoid inserting your feet into the spaces of the seat.
09. Excessive weight may result in overturn and cause damage.
10. Do not put or insert your finger into any part of the chair.
11. Do not put your finger into the gap of the chair.
12. Avoid using the product while front of the seat is lifted.
13. When seating, please do not tilt your body left/right excessively.
14. Do not use the chair for exercise such as push-ups.
15. Do not throw the chair.
16. Do not kick the chair.
17. Do not walk across the chairs.
18. Please get full knowledge for usage of the chair beforehand for more proper use.
19. We do not apply any warranty for any possible injuries, dangers and damages caused by neglect of the above warnings.

CERTIFICATIONS



krede

#803, 171, Gasan digital 1-ro, Geumcheon-gu, Seoul, Republic of Korea

T 82 2 6254 5432

F 82 2 6254 5433

sales@krede.co.kr

www.krede.co.kr

** The dimension and design indicated here are subject to change depending on situations involved with product design and manufacturing.

2025.04.01 Ver.01